



Window-Lite™ by BioBrite

The Next Best Thing to a
INSTRUCTION MANUAL

Real Window

Please read carefully before using this product.



BioBrite, Inc.
4330 East West Highway Ste 310
Bethesda, MD 20814

Congratulations, on your purchase of this fine product! We are confident it will brighten your days.

UNPACKING AND HANDLING

We suggest you save the packing materials in the event you may need to move or ship the Window-Lite at some later date.

COMPONENTS

1. Light Box: (1) a plastic box containing the bulbs and electronics.
2. Diffuser: (1) a thin sheet of translucent plastic.
3. View(s): a scenic transparency.
4. Frame: (1) the front cover for the unit which resembles an actual window frame (in either white plastic or oak wood, depending on model).
5. Anchors: (2) anchors and screws for wall-mounting.

WARRANTY REGISTRATION

LIMITED WARRANTY

BioBrite, Inc. warrants to the original purchaser that this product shall be free of defects in material and workmanship under normal use and circumstances for a period of one year from the date of original purchase for use. When the original purchaser returns the product to BioBrite, Inc., within the warranty period, and if the product is defective, BioBrite will at its option repair or replace the unit. This warranty shall constitute the sole liability of BioBrite, Inc. concerning this product. BioBrite expressly disclaims all other warranties, including, without limitation, the warranties of merchantability and fitness for a particular purpose. No person, firm, or corporation is authorized to assume for BioBrite any other liability in connection with the sale and use of the product. BioBrite and agents and distributors will bear no liability whatsoever for incidental or consequential damages or charges of any kind. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above disclaimer regarding incidental and consequential damages may not apply to you. **THIS WARRANTY SHALL BE EFFECTIVE ONLY IF THE REGISTRATION CARD IS FULLY COMPLETED AND MAILED TO: BIOBRITE, INC., 4330 EAST-WEST HIGHWAY, SUITE 310, BETHESDA, MD 20814 (301-961-5940).** This warranty is void if the product or any of its parts has been damaged or tampered with. This warranty gives you specific legal rights; you may also have other rights which vary by state.

Please complete and return this warranty registration to:

BioBrite, Inc.
4330 East West Hwy. # 310
Bethesda, MD 20814

Name: _____

Address: _____

Telephone: _____

Date of Purchase: _____

Where Purchased: _____

How did you hear about BioBrite?

CHOOSING A LOCATION

Ideally you should locate the Window-Lite lower than you would normally hang a framed picture. (Window sills are most commonly 30" to 48" from the floor. The keyholes for hanging are near the top of the light box; therefore the two wall anchors should be located 58" to 76" off the floor for ideal height). Be sure that the Window-Lite's 8 ft. cord can reach a grounded (3-hole) 110V wall outlet.

HANGING THE WINDOW-LITE

The back of the *light box* is fastened to the wall using the two keyhole slots. The *view* transparency and the *diffuser* (the thin sheet of translucent plastic) slide into the tracks along the sides and bottom of the light box. The *diffuser* sheet is also held firmly in place with a small patch of Velcro placed at the top center of the back of the sheet (See Diagram). Removing the *diffuser* and *view*, gives you full access to the keyhole slots on the *light box*.

The keyhole slots are spaced 14" apart. The Window-Lite will be easily supported by the two self-drilling drywall anchors (provided). In some cases, you may need to use another type of anchor for your wall, such as wood or sheet metal screws.

Decide where you wish to hang the window and measure the height from the ground for the first anchor placement. Place a #2 Phillips screwdriver into the anchor recess, press into the drywall while turning the anchor clockwise until it is seated flush with the wall. Insert the screw until approximately 1/4" remains untightened. Next, measure 14" over to determine the placement of the second anchor, and screw the second one in. The *light box* is hung by positioning the keyhole slots over the screws. The screws should then be gently tightened to hold the unit snug up against the wall. Slide the *diffuser* into the tracks on the front of the unit. Next, slide the *view* into the tracks in front of the *diffuser*. **THE VIEWS DO HAVE A PROPER FRONT AND BACK-** the cut corner of the view should be at the bottom right corner. Finally, the frame is positioned top first onto the front of the *light box* and center

TURNING ON THE WINDOW-LITE

Plug the power cord into a standard 3-hole 110V outlet. The On/Off switch is a push button located under the right side of the *light box*, next to the cord.

CHANGING THE VIEWS

It is very easy to alternate views which you display in the Window-Lite. To change the view, remove the frame by sliding it forward. Next, remove the view. Slide the new view into the tracks, making sure that the cut corner of the view is located in the lower right.

CREATING A VIEW FROM YOUR OWN PHOTOGRAPH

Most full-service photo-finishing stores can make the special transparency the Window-Lite™ uses, which Kodak calls a "Duratran." The dimensions are 18"W x 24"L. The approximate cost to have a photo reproduced in this method is \$70-\$100. It is important to consider perspective and scale before choosing a photo to reproduce, so that the "view" will be realistic.

REPLACING THE FLUORESCENT LAMPS

The Window-Lite uses a highly efficient electronic ballast to power its 3 fluorescent lamps. These premium quality lamps have a rated lifetime of 18,000 hours and will rarely need replacing. Most lighting supply stores sell the fluorescent lamps.

To replace, unplug the power cord from the wall and remove the frame from the unit. Slide both the view and the diffuser out of the track and out of the unit. The fluorescent lamps are now exposed. You may need to remove the tape at either end of the lamps -- it is used for shipping only and is not required for normal use. Twist the old bulb 1/4 of a turn and slide it out. Place the new bulb into the sockets and twist it to complete the connection. Reinsert the diffuser and view, replace the frame, and plug the cord back into the outlet.

CLEANING

The white frame may be cleaned with Fantastic or equivalent. Scuff marks can usually be easily removed with extra-fine sandpaper or steel wool. The wooden frame should only be cleaned with a damp cloth. The surface of the views has a special coating and should only be cleaned with a clean dry cloth.

PAINTING

The plastic frame may be easily spray-painted in just a few minutes.

SERVICE AND REPAIRS

If your Window-Lite is in need of service, please call BioBrite to inform us of the problem and get a return authorization number (1-301-961-5940). **Do not ship it back without an RA#, as it will not be accepted.** Pack the Window-Lite carefully, using the original shipping materials (box and bubble wrap) if possible. **Put your name, phone number, address, and reason for return inside the package.**

SPECIFICATIONS

Weight:	11 lbs (plastic) / 18 lbs (wood)
Dimensions:	28 1/4"H x 24 3/4"W x 4 1/4"D
Power:	110V 60Hz, ~ 45 watts, electronic ballast, grounded 8 foot power cord.
Lighting:	(3) 17 Watt <i>F17T8</i> or <i>FO17T8</i> fluorescent lamps, 4100K