

**Replacing the Bulb**

To replace the bulb (use only a 60 Watt bulb), first unplug the clock from the wall. Remove the globe from the clock by pulling upward. Remove the globe by holding the base with one hand, and pulling up on the globe. Take care not to break the bulb by hitting it with the globe as you do this. **Caution:** If the bulb was recently in use, it will be hot -- let the lamp cool before removing the bulb. Screw in the new bulb completely. Carefully put the globe back on by lowering it over the bulb (the slots on the globe face backwards) and make sure it is fully home and securely held. Plug in the clock, re-set the time, alarm time, and any other settings. Replacement bulbs are available from BioBrite or local hardware stores (ask for a 110 Volt 60 Watt E12 Candelabra base frosted bulb).

**Warranty**

The EZ Wake SunRise Clock is guaranteed against any defect in its manufacture for 12 months from the date of purchase.

**Service**

If your EZ Wake SunRise Clock requires service, please remove the globe and bulb and package the base with a note containing: your name, the address to which it should be returned after servicing, a daytime telephone number, a description of the problem(s) you are experiencing and send it to: BioBrite Service Department, c/o Saville Electronics, 2613 Joppa Terrace, Baltimore, MD 21234. If your clock is more than 12 months old, include a \$25.00 check made payable to "BioBrite, Inc.". If newer, the repair is covered by the warranty.

**WARRANTY FORM**


NAME \_\_\_\_\_

ADDRESS \_\_\_\_\_

\_\_\_\_\_  
TELEPHONE \_\_\_\_\_


DATE &amp; PLACE OF PURCHASE \_\_\_\_\_

MODEL/SERIAL NO. \_\_\_\_\_

**INSTRUCTIONS  
FOR THE****EZ WAKE****SUNRISE CLOCK™****BioBrite, Inc.**

4330 East-West Hwy. Suite 310  
Bethesda, MD 20814  
301-961-5940  
Email: [biobrite@aol.com](mailto:biobrite@aol.com)  
Website: [www.biobrite.com](http://www.biobrite.com)

The **EZ Wake™ SunRise** Alarm Clock is a naturally great way to fall asleep and wake up every day. That's because humans are programmed by nature to wake to the rising sun and sleep when the sun goes down. Waking up to a simulated sunrise can help you start the day feeling more refreshed and ready to go. Falling asleep to a simulated sunset can help you relax and fall asleep more easily. Please read the directions and familiarize yourself with the control buttons and clock display to ensure you get off to a good start with your new EZ Wake Clock.



⚙	=	ALARM SET
PM	=	PM symbol
)))	=	BEEP symbol
A	=	ALARM button
P	=	PROGRAM button
+	=	PLUS button
-	=	MINUS button

**Setting up the EZ Wake Clock**

For best results, place the clock near your bed on a nightstand or bedside table close to pillow level. Plug the clock into the nearest wall plug. NOTE: Until the time has been set, or after a prolonged power outage, the clock display will flash on and off to let you know the time needs to be set.



**Setting the Time**

Make sure the alarm (A) button is pressed in so the sun symbol (☀) is not lit. Press and hold the program (P) button (display reads, “**setC**” for two seconds), then use + and (-) buttons to adjust the time. The time moves rapidly if the + or (-) button is held in. The PM “dot” is lit for PM and off for AM.

**Changing to a 24 Hour Display**

The clock is preset to a 12-hour display. To change to a 24-hour display, make sure the A button is in so the sun symbol is not lit, then press and hold the P button and press both + and (-) buttons at the same time. The display will read “**24 Hr**”. To switch back to a 12-hour display, follow the same procedure and the display will read “**12Hr**”. Note: the “PM” symbol dot is only lit in the 12-hr mode.

**Using the Adjustable Reading Light**

Press and hold the + button to turn the lamp up until it reaches the correct brightness level. To reduce the light level or turn it off, press the (-) button.

**Setting the Wake-Up Time**

Make sure the A button is out so the sun symbol (☀) is lit, then press and hold the P button, (the display reads “**SetA**” for a few seconds). Then adjust the alarm time with + and (-) buttons until desired time is set (Note: default alarm time is 7:00 a.m.). Holding in the + or (-) button will cause the time to change rapidly.

**Turning the Alarm On**

Push the A button so it is out. The display will show the sun symbol (☀) and the wake up time will be displayed for a few seconds. If the light is on, it will slowly fade out, or you can turn it off by pressing the (-) button.

**Disabling the Beeper**

The backup alarm beeper is preset “on” as indicated when the dot next to the Beep symbol, “)))”, is lit. To disable the audible beeper, make sure the A button is pushed out so the sun symbol (☀) is lit, then press and hold both + and (-) buttons at the same time for about 6 seconds until the Beep symbol goes out (you will hear a faint beep as the symbol goes out and the display reads, “**nonE**”). To reverse this, repeat the same procedure until the Beep symbol lights. You will hear a single beep as the symbol lights and the display reads, “**beeP**”.

**Activating the Sunset Sequence**

The Sunset sequence lets the light fade down slowly to help you fall asleep. Many people also find that it's especially useful for small children, encouraging them to shut their eyes and settle down. Manually turn the light on to the intensity from which you wish the sunset to start. Then press the A button so it is out and the sun symbol (☀) is lit to begin the sunset. If the light is at full intensity it will take 30 minutes for the light to go out. The less bright the light is to start, the faster the light will fade out.

**Setting the Night Light - (Blue Model Only)**

In the blue EZ Wake SunRise Model, you can choose the Fade-to-Nightlight option, by having the ALARM button out so the sun symbol (☀) is lit. Press the PROGRAM button and, at the same time, the + and - buttons. Release when the phrase “on nite lite” appears sequentially. If you do not want to use the night light feature, push the buttons again so “off nite lite” appears.